


L'IDRAULICA PER IL FAI DA TE



IDROGAMMA

Gruppo 20.0

20.0

Cassette WC a zaino

20.1

Cassette WC a incasso e placche

## Cassette WC a zaino

|   |      | Codice Art.                            | Descrizione  | N.pzi  | Ord. min. | Codice barra                   |
|---|------|--|--|--------|-----------|--------------------------------|
|    | 1700 | <b>81291034R</b>                       | CASSETTA EXPORT C/RIV.   | 1      | 5         | 8020611047029                  |
|    | 1702 | <b>81301030</b>                        | CASSET. A ZAINO SUPERPIATTA BETA                                     | 1      | 5         | 8020611034371                  |
|    | 1704 | <b>8141PL1</b><br><b>8141PL2</b>       | CASSETTA WC PLUS 1<br>CASSETTA WC PLUS 2                             | 1<br>1 | 5<br>5    | 8020611039116<br>8020611039123 |
|   | 1706 | <b>81351020</b>                        | CASSETTA A ZAINO ARTIKA  | 1      | 5         | 8020611034388                  |
|  | 1708 | <b>81401080</b>                        | CASSETTA A ZAINO SMART   | 1      | 5         | 8020611034395                  |
|  | 1710 | <b>81201000G1</b><br><b>81251000G2</b> | CASSETTA A ZAINO GENIUS 1 PULSAN<br>CASSETTA A ZAINO GENIUS 2 PULSAN | 1<br>1 | 5<br>5    | 8020611034357<br>8020611034364 |
|  | 1712 | <b>81451041C</b>                       | CASSETTA A ZAINO ALFA  | 1      | 5         | 8020611034401                  |
|  | 1740 | <b>8161461201</b>                      | GEMMA 1TASTO C/RUBIN   | 1      | 5         | 8020611044325                  |


## Cassette WC a zaino

|   |      | Codice Art.   | Descrizione   | N.pzi       | Ord. min.   | Codice barra                                    |
|---|------|---|---|-------------|-------------|---|
|    | 1742 | <b>8163360501</b>   | PANAMA 1 TASTO S/RUBINETTO  | 1           | 5           | 8020611044356                                   |
|    | 1744 | <b>8164440141</b>   | CASSETTA OLISTYLE   | 1           | 5           | 8020611044417                                   |
|    | 1746 | <b>8160401201</b><br><b>8160407201</b><br><b>81604072SR</b> | SMERALDO 1TASTO C/RUBIN<br>SMERALDO 2TASTI C/RUBIN<br>CASSETTA SMERALDO S/RUBINETTO | 1<br>1<br>1 | 5<br>5<br>5 | 8020611044301<br>8020611044318<br>8020611044721 |
|   | 1748 | <b>8162411201</b><br><b>8162416201</b>                      | TOPAZIO 1 TASTO C/RUBINETTO<br>CASSETTA TOPAZIO 2 TASTI C/RUBIN                     | 1<br>1      | 5<br>5      | 8020611044332<br>8020611044349                  |
|  | 1760 | <b>8159325101</b>   | CASSETTA WC KARIBA 2008   | 1           | 1           | 8020611039185                                   |
|  | 1762 | <b>8158336500</b>   | CASSETTA WC BIBLO DUO   | 1           | 1           | 8020611039178                                   |
|  | 1770 | <b>8157384090</b>   | CASSETTA WC EURA  | 1           | 1           | 8020611039161                                   |
|   |      |   |   |             |             |   |

## Cassette Wc a incasso e placche

|   |      | <b>Codice Art.</b>  | <b>Descrizione</b>  | <b>N.pzi</b> | <b>Ord. min.</b> | <b>Codice barra</b>                             |
|---|------|---|---|--------------|------------------|---|
|    | 1800 | <b>81520000</b>   | KIT SOST.CASSETTE INCASSO   | 1            | 1                | 8020611047395                                   |
|    | 1810 | <b>81510000</b>   | CASSETTA INCASSO MONOLIT  | 1            | 1                | 8020611039130                                   |
|    | 1812 | <b>8151PLC1</b><br><b>8151PLC1CR</b>                        | PLACCA A 1 TASTO PER MONOLIT<br>PLACCA A 1 TASTO PER MONOLIT CR.  | 1<br>1       | 1<br>1           | 8020611039147<br>8020611047524                  |
|   | 1814 | <b>8151PLC2</b><br><b>8151PLC2CR</b>                        | PLACCA DOPPIO TASTO PER MONOLIT<br>PLACCA DOPPIO TASTO X MONOLIT CR                                     | 1<br>1       | 1<br>1           | 8020611039154<br>8020611047531                  |
|  | 1830 | <b>8153600318</b><br><b>8153603001</b><br><b>8153627001</b> | INCASSO DIAMANTE S/PLACCA C/CAN<br>INCASSO DIAMANTE C/PLACCA 1 TAST<br>INCASSO DIAMANTE C/PLACCA 2 TAST | 1<br>1<br>1  | 1<br>1<br>1      | 8020611044387<br>8020611044363<br>8020611044370 |
|  | 1832 | <b>8154603001</b><br><b>8154603004</b>                      | PLACCA X DIAMANTE 1 TASTO<br>PLACCA X DIAMANTE 1 TASTO CROMO  | 1<br>1       | 1<br>1           | 8020611044394<br>8020611047548                  |
|  | 1834 | <b>8154604041</b>   | PL.CLASSIC X DIAMANTE 1 TASTO CR  | 1            | 1                | 8020611047562                                   |
|  | 1836 | <b>8154627001</b><br><b>8154627004</b>                      | PLACCA X DIAMANTE 2 TASTI<br>PL.DUAL X DIAMANTE 2 TASTI CROMO   | 1<br>1       | 1<br>1           | 8020611044400<br>8020611047555                  |

## Cassette Wc a incasso e placche

|   |      | Codice Art.       | Descrizione                      | N.pzi | Ord. min. | Codice barra  |
|---|------|-------------------|----------------------------------|-------|-----------|---------------|
|  | 1838 | <b>8154627401</b> | PL.CLASSIC X DIAMANTE 2 TASTI CR | 1     | 1         | 8020611047579 |
|   |      |                   |                                  |       |           |               |
|   |      |                   |                                  |       |           |               |
|   |      |                   |                                  |       |           |               |
|   |      |                   |                                  |       |           |               |
|   |      |                   |                                  |       |           |               |
|   |      |                   |                                  |       |           |               |
|   |      |                   |                                  |       |           |               |
|   |      |                   |                                  |       |           |               |